



Oxo salad spinner



- 817123

Simply press down with the palm of the hand to quickly spin dry salad leaves. Press the other button to stop the spinning instantly.
Comes with a lid to keep your salad fresh.

Date d'impression : 31/01/2026