

Shoe horn gripping clamp

This gripping clamp can also be used as a shoehorn to put on shoes without bending down. The clamp holds the shoe firmly in place to make the task easier. ABS and aluminium.

Length: 66 cm.







- 819082

Date d'impression : 15/12/2025