

Telescopic shoehorn



• Shoehorn with a guide to hold the shoe while putting it on

This practical shoehorn helps you to put on your shoes without bending down. You choose the length according to your needs. It is equipped with a clip to prevent the shoe from moving. Chromed steel and polypropylene.

Length from 54 to 75 cm.



- 819086 (On restock - Available from 13/06/2024)

Date d'impression: 12/05/2024