

Stable walking stick tip Gecko



- 816080

- Gives stability to your stick
- Allows you to lift it up with your foot

The Gecko stick tip fits in place of your existing standard tip and gives stability to your walking stick. The walking feeling is much more dynamic and it keeps your stick straight during your breaks. Its star shape is very resistant. It is fitted with non-slip pads on the underside.

Gives stability to your stick

Allows you to lift it up with your foot

Diameter approx. 12 cm.

Fits most 19 mm diameter sticks.